

ASRA Brief Instructions

ASRA Module



Table of Contents

We reserve the right to make changes to the software not reflected in the statements and illustrations contained in these Brief Instructions. Reprinting, translation and reproduction of this publication, in whole or in part, are not authorized without written permission.

Status: 11/2012 Version 3.6

Daimler AG GSP/OR D-70546 Stuttgart http://aftersales.mercedes-benz.com

Order No.: HLI 000 000 13 24 Printed in Federal Republic of Germany / Imprimé en République fédérale d'Allemagne

Welcome	1
The user interface	2
Determine vehicle data	3
"ASRA" module - Work units and flat rates	4
First steps in the "ASRA" module	5
Important functions in the "Define groups" step	6
Important functions in the "Select operation items" step	7
Important functions in the "Edit operation items list" step	8
Search literature ("WIS" module)	9
Add damage code ("SSL" module)	10
Save operation items list	11
ASRA preface	12
Setup, Online Help, Write feedback	13

These Brief Instructions will guide you during your first contact with the application.

Regardless of whether you are a new or experienced user, these Brief Instructions will accompany you as you take your first steps.

You will be shown examples as you are guided step by step through the base functions of the "ASRA" module.

A separate set of Brief Instructions is available to provide more detailed information about the "WIS", "SSL" and "MSS" modules.

The step-by-step instructions are marked with **1**, **2**, etc. Additional information is marked with **A**, **B**, etc.

If you have further questions that are not covered in these Brief Instructions, you can also access extensive Online Help.

Welcome

ASRA makes many things easier - from the start to the end of the order

As ASRA development continues, additional functions have been added to its previously available functions.

Modular design and flexible operation

The application is modular in design. The central **vehicle identification** serves as a basis for successful searches for documents, damage codes, maintenance scopes and work units.

The "ASRA" module is an electronic catalog of work units and flat rates that facilitates the fast and reliable search for operation items and working times. The "ASRA" module also includes additional operations, included work texts, notes and graphic representations of vehicle parts.

The information obtained using the "ASRA" module forms the basis for creating *cost estimates, orders and invoices*. The output interface allows ASRA data to be integrated into your Dealer Management System.

The available functionalities are enabled by means of your access authorization. The application differentiates among the following access authorizations:

Access authorization	Available modules
WIS	"WIS", "SSL", "MSS" modules
ASRA	"ASRA", "SSL" modules
WIS/ASRA	"WIS", "SSL", "MSS", "ASRA" modules

Overview of functions

С

B "ASRA" module			"WIS" C module	D "SSL" module
Define groups	Select operation items	Edit operation items list	Search literature	Determine damage code
Chapter 6	Chapter 7	Chapter 8	Chapter 9	Chapter 10

The central vehicle identification is where the vehicle data determination occurs, which is the basis for nearly all other steps.

- Take your *first steps* with the "ASRA" module and get to know how it operates.
- Use the "WIS" module to search the *literature for repair work* relating to an operation item.
- Use the "SSL" module to determine a *damage code* for an operation item and add it to the existing operation items list.

The user interface



The application has a modularly designed user interface, which offers you flexible control.

The user interface is clearly arranged, divided into *different areas*.

Vehicle identification

The central vehicle identification serves as a basis for successful searches for documents, damage codes, maintenance scopes and work units. The vehicle identification is valid for all modules.

Module bar

The available modules are shown in the Module bar. You can easily switch between modules by clicking the icons.

Standard functions

The standard functions apply to all modules.

Control bar

The Control bar uses logical steps to define the efficient use of the system.

Module area

In the module area, the corresponding controls are displayed depending on the selected module.



🛱 WIS	/ASRA - brown
	Vehicle identification number WDB 💌 2030061F000264
9	CAR ▼ 22 203 C-Class ▼ 12 C 220 CDI ▼
	1. Define groups 2. Select operation items 3. Edit operation items list
\heartsuit	Direct entry of operation number: 💶 📄 🖹 🔊 🐞
ASRA	Groups ASRA picture
3	Keyword: Group: 20
55L	Coup notes
MOO	■ Pictu e: Components of engine cooling system. ■ 1010 Cooling and heating system
	- 1140 Coolant - 1285 Water pump
1	2470 Paoline system thermaster
	•

- **Tooltips** are provided to explain icon functions. When you position your mouse pointer over an icon, a tooltip providing a brief description of the function appears.
- If you have further questions that are not covered in these Brief Instructions, you can also access extensive **Online Help**.
- In the tree structure one or more groups can be selected by clicking on the **option buttons** \checkmark .

Determine vehicle data

In the "Vehicle identification" area, you determine the *vehicle data* that serve as the basis for nearly all other steps.

The more specific the vehicle data, the more precise the result of your search will be.

Vehicle data can be determined using one of the following methods:

- Variant 1: Determine vehicle data with a Vehicle Identification Number You must enter a Vehicle Identification Number.
- Variant 2: Determine vehicle data with Vehicle type, Family and Model code by selecting in the pull-down menus.
- Variant 3: Determine vehicle data with Display model designation Q.

You must select the Vehicle type **and/or** Family **and/or** Type code **and/or** Model **and/or** Engine model designation in the pull-down menus.

Entering a vehicle identification number is always advantageous if your computer has an interface to the vehicle datacards in EPC. In this case, the datacard is evaluated.

	•) (2
🚔 WIS	/ASRA - brown		
File C	ptions Help		
	Vehicle identification number	B 🖌 2030061F000264	
甼	CAR 🔻 22 203 C-Class 🔻 12 C	220 CDI 🔻	

🛱 WIS/ASRA - brown
File Options Help
Vehicle identification number WDB 💌 2030061F000264
WDB2030061F000264
WIS WDD20404415L000163



Become familiar with the variants for the optimum determination of vehicle data using examples:

Variant 1: Determine vehicle data with a vehicle identification number

Using the pull-down menu, select the World Manufacturer Code *WDB* for Germany.

Enter vehicle identification number **2030061F000264** in the input field and confirm your entry by pressing RETURN 군.

The vehicle data are now set.

2

Click the pull-down menu to open the *"History"*. The last vehicle data you entered in WIS, ASRA and EPC are stored there.

If you have an interface to EPC net on your computer, you can access the **datacard** by clicking the **k** icon after entering a vehicle identification number.







Variant 2: Determine vehicle data with Vehicle type, Family and Model code

- Click the 🛷 icon to delete the vehicle data used previously.
- 2 Using the "Vehicle type" pull-down menu, select the vehicle type "Car".
 - The "Family" pull-down menu expands. All families available for the vehicle type are displayed.
- 3 Enter the family *22* in the "Family" entry area of the pull-down menu.
 - Select the family *22 203 C-Class* with the mouse in the "Family" pull-down menu.

4

The pull-down menu "Model code" is shown expanded.





ASRA model design	ation				
Vehicle type	Family	Model code	Mortel		
abiata tana	Family	Model code		Online desclored as	Cingine U
enicie type	~	~	Modelwidder designation	Sales designation	Engine number
JAR WAD					
ight transporter					
leavy transporter					
RUCK					
US					
JNIMOG					

Enter the model code *12* in the input area of the "Model code" pull-down menu.

The list is filtered more precisely with each entry. If only the desired model code is displayed, apply the model code by pressing RETURN [].

The vehicle data are now set.

Variant 3: Determine vehicle data with Display model designation

Task:

5

The installability is to be determined for the major assembly 722.695 (automatic transmission).

- Click the 🤏 icon.
- The "ASRA model designation" window opens.
- Click the "Engine" option button.
- The "Engine" column is moved to the left. The installability is determined based on an engine.



				I a a a a a a a a a a a a a a a a a a a
Engine () Engine number 647961 () 647961	Model ○ ModelModel designal. Sales designal. 211616	Vehicle type O Vehicle type CAR Y CAR	Family Family s Stationwagon	Model code Model code 3 E 270 CDI (T) M 13 E 270 CDI (T)

- Enter the engine model designation *647.961* in the input area of the "Engine" pull-down menu and confirm the entry with RETURN <a>[].
- The vehicle model designations in which the engine is installed are shown in the Model list.
- Select the desired vehicle model designation and click on the "OK" button.
- The installability is determined.
- The vehicle data are now set.

4

In these Brief Instructions, the determination of operation items and flat rates is described in relation to the "ASRA" module.

A separate set of Brief Instructions is available to provide more detailed information about the "WIS", "SSL" and "MSS" modules.

"ASRA" module - Work units and flat rates

	A B		
	Ť Ť		
章	學 //IS/ASRA - brown		
Fil	File Options Help		
ē	Vehicle identification number VDB v 2030 561 F000264 v CAR x 22 203 C-Class x 12 C-220 CDL x v	🗸 河 🥔 🗓 🤞	۵ 🗠 🔊
W	W B 1. Define groups 2. Select operation items 3. Edit operation items list		
8	🖤 Direct entry of operation number: 🔄 🖉 🔑 📝 🔊		
AS	ASRA Groups ASRA picture		
	Veword: Image: Construction of the second		

ASRA is the german abbreviation for *operation texts, standard texts, flat rates and work units.*

The "ASRA" module lets you quickly search for operation items and working hours.

You can access the "ASRA" module by clicking the \bigotimes_{ASRA} icon in the *Module bar*.

The following process steps take place within the "ASRA" module:

- 1. Define groups
- 2. Select operation items
- 3. Edit operation items list

These process steps are carried out in the established sequence and correspondingly displayed in the *Control bar*.

The next step is activated in the Control bar as soon as **all** of the required information has been entered in the current step.

First steps in the "ASRA" module

2	•	
章 VIS/ASRA - brown		
Fild Options Help Vehicle identification number WDB 2030061	F000284	🔒 <i>A</i> 🍫 🔒 🖬 🏈 🔤 🅸
CAR ¥ 22 203 C-Class ¥ 12 C 220 CDI ¥		
1. Define groups 2. Select operation items 3. Direct entry of operation number:	Edit operation items list	
APRA Comps Veryword Mathematication Veryword Difference information Veryword		

In the "ASRA" module, the search for operation items is carried out first by defining groups. The selected operation items can be edited further in the other steps.

In the vehicle identification, the vehicle data must be determined using a vehicle identification number or using model designation information.

Task: You are looking for operation items on the complaint Coolant loss with consequence replace radiator.

Determine the vehicle data as described in Chapter 3.

Click the \bigotimes_{ASRA} icon in the Module bar.

The "ASRA" module is displayed with the "Define groups" step activated.



Next you must *define the groups*. This can be done by using either the tree structure or an ASRA picture.

Define groups

Variant 1: Define groups with the tree structure

Use the scroll bar to go to group 20.

Click the 🛨 icon.

3

(4)

6

The subgroups will be shown. You have the option of selecting individual subgroups or the entire group.

- In this example, select the group 20.1010 using the option button \checkmark .
- The group is displayed in the "Selected groups" list.
- The "Select operation items" button in the Control bar is activated. This means that all information required for the "Select operation items" process step has been entered.

😤 WIS/ASRA - Mercedes-Benz & smart - brown							
File O	e Options Help						
	Vehicle identification number WDB 🗸 2030061F000264 💌						
9	CAR 🔻 22 203 C-Class 💌 12 C 220 CDI 💌						
wi5	1. Define groups 2. Select operation items 3. Edit operation items list						
	Direct entry of operation number: 📄 🖹 👔 🐞						





ኞ WIS/ASRA - Mercedes-Benz & smart - b			rown	
File O	ptions Help			
	Vehicle identificatio	n number WDB	✔ 20300)61F000264
甼	CAR 🔻 22 203 C	Class 🔻 12 C 21	0 CDI 👻	
wis	1. Define groups	2. Select operati	on items	3. Edit operation items list
	Direct entry of opera	ation number:	E	🔊 🔊 🐌

Define groups

Variant 2: Define groups with an ASRA picture

Use the scroll bar to go to group 20.

Click the 🛨 icon.

6

8

- The available ASRA pictures are displayed.
- Select the picture title of the ASRA picture in the tree structure.
- The ASRA picture is displayed.
 - Select group number 3865 Radiator in the ASRA picture.
- The group is displayed in the "Selected groups" list.
- The "Select operation items" button in the Control bar is activated. This means that *all* information required for the "Select operation items" process step has been entered.
- Click the "Select operation items" button in the Control bar.
- The operation items are displayed.

e c	iptions Help
7	Vehicle identification number WDB 💌 2030061F000264
f	CAR * 22 203 C-Class * 12 C 220 CDI *
n5	1. Define groups 2. Select operation items 3. Edit operation items list
D	Direct entry of operation number:
SRA	\$° ≌' ★ 🐌
\$	Z Gr/No/Line WU U H Operation text
SL	20-1010-01 🗹 ZM 🔰 Cooling and heater system for leaks using pressure tester Check, record diagnosis
	20-1030-01 🗹 ZM 🔄 Cooling and heating system Rinse
10	20-3865-07 🔲 043 🔮 Radiator Remove/install
r	Z 20-4300-01 🕑 003 🔮 Extra work for: radiator Remove/install Veh. w/ automatic transmission
ISS	

Next, in the step "Select operation items" you can display the *Included work, Notes and Additional operations* and select the operation items to be carried out.

Select operation items

12

(13

- Click the **()** icon to display the included work text. Close the included work text by clicking the Close button.
- Click the 🚞 icon to display the additional operations.
- Click the 🔜 icon to display the datacard. If necessary, take into account information from the datacard when determining additional operations.

The datacard can only be shown if the vehicle data were specified using a vehicle identification number and EPC is available.

- Use the option buttons vec to select the operation items (as shown in the picture).
 - The selected operation items are entered in the Operation items list. The next step is displayed as activated.
 - Click the "Edit operation items list" button in the Control bar.
 - The operation items list is displayed.

Vertical identification number Vertical identification number Vertical identification number Vertical identification number CAR > 22305-Class 22 2020-Class 22 600-Class Vertical identification number 1 Define groups 2 6 600-Class Vertical identification number Vertical identification number 2 All to the identification number Vertical identification number Vertical identification number 2 All to the identification number Vertical identification number Vertical identification number 2 All to the identification number Vertical identification number Vertical identification number 2 Output Vertical identification number Vertical identification number 2 Vertical id	Options Help										
VAR = 22233-C-Class = 12 C 228 CDI = 1. Contemporter 2. Select carditon here: Image: Contemporter for the contempor	Vehicle identification number	/DB 🖌 2030061F000264		~			۵ 🔇	/ Q	i (۵	1
Image: Source provides terms Setted coperation terms Image: Source provides terms Image: Source provides terms <t< td=""><td>CAR - 22 203 C-Class - 12</td><td>C 220 CDI 👻</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></t<>	CAR - 22 203 C-Class - 12	C 220 CDI 👻									
Total III 00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control III 00 Control III 00 Control III 00 20-400-00 Control IIII 00 Control IIII 00 Control IIII 00 20-400-00 Control IIII 00 Control IIII 00 Control IIII 00 20-400-00 Control IIII 00 Control IIII 00 Control IIIII 00 20-400-00 Control IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	1. Define groups 2. Select op	peration items 3. Edit operat	ion items list								
Graduatione VU VI VI </td <td>/ 🖽 🏞 🕹 🎍 🖗 🔊 🥄</td> <td>🖞 🛃 🛃 😒 🔆 Order r</td> <td>iumber:</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	/ 🖽 🏞 🕹 🎍 🖗 🔊 🥄	🖞 🛃 🛃 😒 🔆 Order r	iumber:								
Total: 050		olding and heading system in which for claded Removek on the system of t	Prove	Uc Vansmission	ck, record dis	ignosis					
1018. 000	Total: 860										
	rolai, 050										

The determined operation items are displayed in the "Edit operation items list" step and can be edited there. The working hours are added up.

The *operation items list* can be adapted as required. For example, ZM items can be overwritten and operation items can have a damage code added to them.

Overwrite ZM items

16)

Ð

Click the *"ZM" (time prescribed by foreperson)* input field and enter the corresponding work unit (e.g. 3) or the corresponding number of hours (e.g. 0.2). Confirm the entry with RETURN [].

The new working hours are calculated and then displayed as <u>underlined</u> text.

The *information field "Total"* shows the working hours determined for the workshop order.

Option	8 Help
Veh	cle identification number WDB 💙 2030061F000264 💙
CAF	▼ 22 203 C-Class ▼ 12 C 220 CDI ▼
1.[efine groups 2. Select operation items 3. Edit operation items list
) 🖻	🌮 🛼 🗍 🦸 💭 🔐 🛃 🥍 🖉 ጵ Order number:
^{VA} Gr/l	lo Line WU U H Operation text
20-1	300-01 003 0 Extra work for: radiator Remove/Install Veh. w/ automatic transmission
20-4	010-08 043 🔍 Radiator replace
2	
2)	
2)	
2)	

If necessary, you can click the \clubsuit icon to add a *damage code* to a selected operation item.

A module change into the "SSL" module is required. This function is described in detail in Chapter 10.

You can select an operation item and click the ricon to search for *literature* on the selected operation item if necessary.

A literature search can only be performed if you have an access authorization for the "WIS" module.

A module change into the "WIS" module is required. This function is described in detail in Chapter 9.

You can click the si icon in the Standard icon bar to *print* the operation items list if necessary.

You can save the operation items list if necessary by clicking the $\textcircled{\blacksquare}$ icon.

This step is described in detail in chapter 11.

Important functions in the "Define groups" step



In the "Define groups" step, you define the groups for which operation items are to be determined.

The groups in the "ASRA" module are sorted by design groups.

In the *Direct area*

operation numbers and customer issues can be entered without specifying groups. You can also access saved operation items lists.

One or more groups can be selected using the *tree structure*.

In addition to the tree structure, groups can also be defined by using the *ASRA picture*.

The following generally applies:

In the "ASRA" module, the groups can be determined with the tree structure or the ASRA picture. The "Select operation items" button is not shown as activated in the Control bar until **all** necessary criteria are determined.



Functions in the Direct area

Direct entry of operation number:

When a known (6-digit) **operation number** is entered, the operation item is transferred to the subsequent step.

If there are additional operations, then the "Select operation items" step with all of the additional operations is expanded. If there are no additional operations, then the operation item is added directly to the Operation items list.

With the bicon, saved operation item lists can be **opened** again for further processing.

The opened file contains the saved vehicle data and the operation items list with all saved operation items.

You can click the is icon to add a *customer request* (= free text) to the operation items.

The *icon removes* all selected groups from the "Groups" tree structure.

With the **1** icon, the group notes of all selected operation items can be **displayed** in **one window**.



"Groups" selection area

In order to be able to determine operation items in the "ASRA" module, you must first determine groups.

The groups in the "ASRA" module are sorted by design groups.

Only the selected groups are used to determine the operation items.

Each group or subgroup that you select in the tree structure by clicking the option button \blacksquare is automatically transferred to the list of selected groups.

- Click the Group notes icon to view special technical information for a group, e.g. which operations are included in the selected group.
- Opening the "Keyword" pull-down menu activates the keyword directory.

With the "Keyword" pull-down menu, you can use keywords to search for groups. Selecting the keyword in the "Groups" tree structure selects the corresponding group.



"ASRA picture" selection area

Clicking the picture title displays the ASRA picture.

Each ASRA picture is uniquely assigned to a vehicle family and a design group. The ASRA picture contains sketches or schematic representations of vehicle components and mouse-sensitive fields.

Clicking the sensitive fields in the ASRA picture transfers the associated entries to the "Selected groups" selection list.

The \mathbb{N} icon displays the picture in a separate window. You can close the separate window again by clicking the \mathbb{N} icon.

Important functions in the "Select operation items" step

Α

С

WIS/ASRA - brown File Options Help Vehicle identification number WDB v 2030061F000264 辱 CAR 👻 22 203 C Class 👻 12 C 220 CDI 👻 W/S 2 Edit operation items list 1 Define arour on rumher: Direct entry ASRA 2 7 GriNoff ine WU U H Operation text 15-0640-0 15-0641-01 003 🙂 Individual parts of preglow system Check according to fault code 20-1010-01 714 Cooling and heater system for leaks using pressure tester Check, record diagnosis 20-1030-01 ZM Cooling and heating system Rinse 20-3865-07 843 🙂 Radiator Remove/install 20-4300-01 Extra work for: radiator Removelinstall Veh. w/ autor 20-4000-08 043 🙂 Radiator replace Extra work for: radiator Removalinetall l/ah w/ automatic transmission 20-4200-01 002 0 54-1011-01 003 0 G Short test perform EPC

In the "Select operation items" step, you select the *operation items* to be carried out, which adds them to the operation items list. You must take into account the included work texts and notes as you do this.

In the selection list, a distinction is made between a **Stand-alone operation** (shown in bold print), a Linked operation (shown normally) and an *Additional operation* (show in italics).

Click the option buttons \mathbf{V} to transfer the associated operation item into the operation items list.

The time allowed for an operation item is displayed in the "WU" column.

The display format of the time allowed can be preset in Setup.

- **WU** Work unit (1 WU = 5 minutes)
- *Hrs.* Decimal hours (0.1 hours = 6 minutes)
- ZM Time prescribed by foreperson For operation items that are designated with ZM, a time can be prescribed by the foreperson. The ZM item is overwritten in the "Operation items list" step.

Direct entry of operatio	n numb	er:	
🗊 😒 📽			
Z Gr/No/Line N	NU U	н	Operation text
	ZM		Preglow unit Check (after quick test)
	003 🙂		Individual parts of preglow system: Check according
20-1010-01 🔽	ZM		Cooling and heater system for leaks using pressure tester Check,
20-1030-01 🔽	ZM		Cooling and heating system Rinse
20-3865-07 🔲	043 🙂		Radiator Remove/install
Z 20-4300-01 🗹	003 🙂		Extra work for: radiator Removelinstall Veh. w/ automatic transmission
20-4000-08 🔽	043 🙂		Radiator replace
Z 20-4300-01 🛛 🗹	003 🙂		Extra work for: radiator Removelinstall Veh. w/ automatic transmission
54-1011-01 🗹	003 🙂	Θ	Short test perform
		Т	

Additional operation: By clicking the 🗂 icon, you and display or hide the additional operations for an operation item.

Included work: By clicking the **O** icon, you can obtain information on the suboperations of work information.

Note: By clicking the ⁽¹⁾ icon, you can obtain information on the special technical consideration of an operation item.

You can select an operation item and click the right icon to search for *literature* on the selected operation item if necessary. If documents pertaining to the operation item are available, they will be displayed in the "WIS" module.

A literature search can only be performed if you have an access authorization for the "WIS" module.

Clicking the *icon* allows you to enter any number of **customer requests** as free text. These are added directly to the operation items list.

The $\not\approx$ icon is a toggle switch used to select \square or deselect \square all operation items.

With the **to** icon, the group notes can be displayed.

Enter a known **operation number** in the input field Direct entry of operation number: _____ and confirm by pressing RETURN 🕑 to enter this number directly in the operation items list.

Important functions in the "Edit operation items list" step

WIS/ASRA - brown
Vehicle identification number [VDB 🖌 2030061F000284 💌 📃 🍰 🥔 🆓 🕵 🚺 🍭 🥁 🏠
CAR ¥ 22 200 C-Class ¥ 12 C 220 CDI ¥
1. Define groups 2. Select operation items 3. Edit operation items list
💆 🛅 🏶 🎄 🔺 🦸 🔊 🎦 🖼 🛃 🖄 🔆 Order number:
Generation VU III Description D-450901 Dispersion Constraint and the Address Status Constraint and the Address Status D-450901 Dispersion Constraint and the Address Status Constraint and the Address Status D-450901 Dispersion Constraint and the Address Status Constraint and the Address Status D-450901 Dispersion Constraint and the Address Status Constraint and the Address Status D-450901 Dispersion Constraint and the Address Status Constraint and the Address Status
r c
Totat: 050 -B

In the "Edit operation items list" step, the determined operation items are displayed in the operation items list and the working hours are totaled.

The operation items list can be modified as required, e.g. ZM items (times prescribed by foreperson) can be overwritten and operation items can be supplemented with a damage code.

The *"Total" information field* shows the time calculated for the workshop order (in WU or hours).

ZM = Time prescribed by foreperson

For operation items that are designated with ZM, a time can be prescribed by a foreperson.

By clicking in the "ZM" input field, you can enter your own time allowed.

Icons and functions of the Toolbar

For later processing, you can save the operation item list with the end icon.

This step is described in detail in chapter 11.

You can select an operation item and click the reasonable icon to search for *literature* on the selected operation item if necessary. If documents pertaining

to the operation item are available, they will be displayed in the "WIS" module.

A module change into the "WIS" module is required. This step is described in detail in chapter 9.

Click the 3 icon to add a *damage code* to a selected operation item.

A module switch into the "SSL" module is required. This step is described in detail in chapter 10. You can use the Δ \forall icons to *move* the selected operation items *up or down*.

Click the *icon* to *clear* the selected operation items from the operation items list.

Click the \square icon to *copy* the selected operation items.

With the is icon, you can enter as many *Customer issues* as desired as freely selected text. These are transferred directly to the operation items list.

The $rightarrow i con is a toggle switch used to select <math>\square$ or deselect \square *all operation items*.

The Order number: input field allows you to enter an order number. This *order number* is shown on the printout of the operation items list.

	ptions Help	
	Vehicle identification number WDB 🚽 2030081F000264 🛛 🚽 🔜 🚔 🤌 🦓 🚺 🧇 🖂	ł
	CAR 🔻 22 203 C-Class 🔻 12 C 220 CDI 💌	
•	1. Define groups 2. Select operation items 3. Edit operation items list	
)	🕮 🌮 🖧 🗍 🦸 😰 📴 🖼 💥 😿 🖍 Order number:	
8A	GrNoLine WU U H Operation toxt	GKZ
.	20-1030-01 ZM Cooling and heating system Rinse	
1	20-400-09 00 0 Reditor replace	
	20-1010-01 ZM Cooling and heater system for leaks using pressure tester Check, record diagnosis	
2	00-9480-01 ZM Tire tread di pth in mm LF: RF: LR: Check	
8	🛱 Add/change operation item	
-		
٩	Gr. No. Line WII Operation text GK7	

Vehicle identific	ation number	r WDB 🕶 203	D061F000264	¥			۵ 🎝	> 🔍	🖪 🧇	\geq
CAR 🔻 22 20	3 C-Class 🦷	r 12 C 220 CDI 🔻								
1. Define grou	ps 2. Sele	ect operation items	3. Edit operati	on items list						
🖺 🌮 🖧	4 🔶 🝃) 🔓 🗃 🛃	🝸 🔆 Order ni	umber:						
Gr/No/Line	WU U H	Operation text		-						
20-1030-01	2M 003 U	Extra work for: ra	ator Remove/in	e stall Veh. with aut	omatic transmissi	on				
20-4000-08	043 U	Radiator replace Cooling and heat	er system for le	aks using pressu	re tester Check.	record d	iannosis			
00-9480-01	ZM	Tire tread depth	1 mm LF: RF:	LR: RR:	Check		- .			
🛱 Overwrite	placeholde	er -								
Placeholder	1: 4								٢	
Placeholder Placeholder	1: 4		•							
Placeholder Placeholder Placeholder Placeholder	1: 4 2: 4 3:		3						2	
Placeholder Placeholder Placeholder Placeholder Placeholder	1: 4 2: 4 3: 4:								*	
Placeholder Placeholder Placeholder Placeholder	1: 4 2: 4 3:		•							
Placeholder Placeholder Placeholder Placeholder Placeholder Operation te:	1: 4 2: 4 3: 4: xt Tire tread	depth in mm LF:4 P	RF:4 LR: RR:	Check					*	
Placeholder Placeholder Placeholder Placeholder Placeholder Operation te:	1: 4 2: 4 3: 4: xt Tire tread	depth in mm LF:4 f	RF:4 LR: RR:,	Check					*	

With the icon, you can add **one** or **more of your own operation items** to an operation item list in the "Add/change **operation item**" window. Enter the group (2-place) and the operation text in the "Add/change operation item" window.

The work unit (WU) can be entered directly here or later in the operation items list. Entry of the warranty ID (GKZ) is optional.

The operation item is displayed in the operation item list with the \fbox{Add} button.

With the error icon, you can overwrite the placeholder (.....) in ASRA operation texts in the *"Overwrite placeholder"* window.

The icon is only activated if placeholders are present in the selected ASRA operation text.

The texts of the individual placeholders can be entered in the "Overwrite placeholder" window. A preview is shown in the "Operation text" information field.

The changed operation text is displayed in the operation item list with the Apply button.

Click the \bigcirc icon in the Standard icon bar to **print** the operation items list.

Search literature ("WIS" module)



The "WIS" module is a submodule within the application.

The The transfers the operation number of the selected operation item to the "WIS" module. In the "WIS" module, the search literature function starts in the "Operation number" search mode.

Task: You search for literature on the operation item *20-1010-01*, *Checking cooling and heating system with pressure device for leaks, establish findings*.

Select the operation item.

Click the ኛ icon.

The "WIS" module is started in the "Start search" step.

The "Operation number" search mode has been activated. The available literature on the selected operation item is searched for.

The following options are possible:

- If there is available literature pertaining to the selected operation item, the "Show documents" step is displayed in the "WIS" module.
- If there is no available literature pertaining to the selected operation item, a corresponding message appears in the "WIS" module. The search criteria can be modified by clicking the "Change search criteria" button.

If no list line is marked in the operation items list, the ricon is shown as inactive.

Add damage code ("SSL" module)



The "SSL" module (damage code) is a submodule within the application.

In the "SSL" module, clicking the \clubsuit icon allows you to determine the damage code associated with a particular operation item.

Task: You search for a damage code on the operation item 20-1010-01, Checking cooling and heating system with pressure device for leaks, establish findings.

Select the operation item.

Click the ᅯ icon.

2

3

- The "SSL" module is started in the "Specify damage code" step. The associated group is expanded.
- Click the \pm icon of the group **20** and select the subgroup **20.20**.
- The pictures are shown in the tree structure.
- In the tree structure, select the picture *Radiator, coolant hose*.
- The damage code picture is displayed.



- Click the fault location *radiator* either in the selection list or in the picture.
- Click the fault type *leaky*.

6

7

8

- Click the warranty type original equipment.
- Click the repair type **Repair using material**.
- The damage code is determined and can be read in the information field.
- Click the "Send damage code to ASRA" button.
- The "ASRA" module is opened. The added damage code is inserted below the operation item.

Save operation items list

Operation items lists can be **stored** for further processing. The saved file contains the vehicle data and the operation items list with all operation items.

The "Save operation items list" window is automatically displayed if you have transferred at least one operation item to the operation items list and then carry out the following action:

- You change the vehicle data in the vehicle identification.
- Click the 🛄 icon in the "Edit operation item list" step.

- You open an operation items list already stored with the 違 icon in the "Define groups" step.
- You end the application.

🛱 Save operati	ion items list	
The operation iter	ms list has not y	et been saved. Do you wish to save it now?
Look in:	🚞 joborder	💌 🤌 📂 📖
My Recent Documents Desktop My Documents		1 2
My Computer		T T
(
My Notwork	File name:	joborder.bd
Places	Files of type:	ASCII, UTF8 and UNICODE files (*.bd, *.utf, *.ucs, *.xfr)
		Yes Cancel
		3

- Assign a file name. You have the following options:
 - Use the preset file name (e.g. joborder)
 - Enter a new file name in the input field.
 - Select an existing file name. This operation items list is then overwritten.
- 2 If necessary, change the file type by entering a different file extension (e.g. .txt, .utf, .ucs).
 - The folder path and the file extension (e.g. .txt) are preset based on the settings made in Setup.

Click Yes .

The operation items list is saved.

In the "Define groups" step, click the 📄 icon to reopen saved operation items lists for editing. Opening a saved operation items list does not require prior specification of vehicle data.

ASRA preface

l	🛎 ASRA preface
	STANDARD TEXTS AND FLAT RATES 08/09
	Modifications/New Features for Passenger Cars The following vehicles have been added or the index of model codes has been expanded:
	639 Vito/Viano Family 26 (Book 03/06)
	119/126 Crewbus A3 (M272) (China), Model code 91 111 CDI Crewbus A3 (China), Model code 92 115 CDI Crewbus A3 (China), Model code 92 2.8/35 Viano A2Matro Polo (M 272) (China), Model code 94 2.2 CDI Viano A2, 2.2 CDI Marco Polo (China), Model code 95
	Modifications/New Features for Commercial Vehicles The following vehicles have been added or the index of model codes has been expanded:
	No modifications/new features
ľ	Print Close

 $\overline{\mathbf{x}}$

The ASRA preface describes *modifications and new features* in the latest ASRA release as well as other general information.

The ASRA preface can be accessed from the Menu bar by selecting "Help/ASRA preface" or by pressing the function key F5.

- The ASRA preface is updated monthly.
- The ASRA preface can be printed if necessary.

Setup, Online Help, Write feedback

	SRA - brown				
File Opt	ions Help				
9	etup F2				
	B				
🛱 Setup					
General Lan	guage selection W	S ASRA MSS	1		
Paper forma	at A4 💌 er sheet	 Portrait forma 	it 🔿 Landscape fi	ormat	
Basic prefer	ences	- 4-			
Hide hit l	ist when displaying c	ocument			
l.					

Setup

The Setup function allows you to change the basic preferences for your user ID.

In any case, you should check to make sure that your Setup settings match your personal requirements. This is the only way to ensure that the available functions are used in the most effective manner possible.

Open Setup window

The setup window is opened in the Menu bar with "Options/ Setup" or the F2 function key.

Use the panels to switch between the general basic preferences and the basic preferences for the individual modules.

"General" tab

The "General" tab is where basic preferences are set that apply to all modules.

- The desired paper format setting for the printout.
- The basic default settings.

ģ	🛱 Setup		
			4
	General Langu	age selection WIS ASRA MSS	
	Dialog langu	age	
I	User interface	English	
	-Document la	nguage priority	
	Priority 1	English 🗸 Conduct document search with priority 1 only	
I	Priority 2	French	
	Priority 3	Spanish	
	Available pu	blications	
	D/F//NL/DK/S/	VO/TR/RU/PL Standard	
	GB/E/P/SF/GR	J Standard Standard	
t			
F			OK Cancel Apr

"Language selection" tab

Use the "Language selection" tab to make language settings that apply to all modules.

Selecting the dialog language sets the language for the *user interface*. This affects the buttons and tab labels, for example.

Setting the priorities 1 – 3 allows you to stipulate which languages will have priority when searching for documents.

Each publication contains various languages. These are labeled with the country ID.

The display of available publications depends on your access authorization.

General Language selection WIS ASRA MSS	
Work units	
Time prescribed by foreperson (ZM) can be overwritten	
Time mode: @ Will _ O Hours	
Time mode. Who O Hours	
Region: 00 Domestic 💌	
Saving of operation items list	
Directory for output file:	
C.tempwBCASEgoborder	
ioborder.txt	
ASRA data status: 1012	

"ASRA module" tab

The activated option button 🗹 establishes that the ZM items (time prescribed by foreperson) in the operation items list can be overwritten.

The default setting of the time mode and region is carried out with the WIS/ASRA access authorization and is not to be changed. Otherwise, the correct computation of the flat rates is not ensured.

The default setting for Germany and Austria is the "WU" time mode and the "Domestic" region. In all other countries, "Hours" must be set as the time mode and "Foreign" as the region so that the flat rates are correctly calculated and displayed and are valid for warranty invoicing.

Default setting for the folder path in which the saved operation items lists are stored *locally* on the client.

Defines the standard file names under which the operation items list can be saved.

The information field shows the ASRA data status. Example: 1012 = month 10, year 2012

		(B						4	
🚔 W IS	ASRA -	Mercedes-Benz & sma	rt - brown							
File	Options	Help								
	Vehicle	WIS/ASRA Help	F1		1.8	A		Ô	A /	
		ASRA General Prefac	9 F6	<u> </u>	- X	24	S	- 1		A A A A A A A A A A A A A A A A A
뿌	Vehicle	ASRA Preface	F5							
WIS		What's New	Umschalt+F1							
	1. De	Client information		3. Edit operation items list						

Online Help

The application comes with an *extensive Online Help system* that can assist you with any question you may have about using the program.

This function provides assistance, regardless of whether you need information on the function of an icon, would like to obtain detailed information or require *step-by-step instructions*.

You can open the Online Help notes as follows:

"Help" icon

The *icon* offers the *context-sensitive* help, *e.g. for the current step*.

You can navigate to other help topics with links or the Navigation bar.

Menu bar

When opening the Help notes from the menu bar or by pressing the function key F1, a *general help starting page* will appear. Here you can choose between various help topics. You can navigate to other help topics with links or the Navigation bar.



Links in running text

Links in running text are marked with colored text. Selecting the link displays detailed information.

Additional links

Additional links are marked with an arrow and colored text. Selecting the text displays detailed information or additional information.

Links in overview graphics

Most of the overview graphics in the Help notes are mousesensitive. In sensitive areas, the mouse pointer changes from a hand ${}^{(h)}$ and displays additional detailed information when an element in the graphic is clicked.

Navigation bar

All Help topics are also included as entries in the navigation bar.

When you open the Online Help for the first time, it is advisable to read the Help topic "*Information for new and experienced users*".

"Start search" tab

With the "Start search" tab, the online help can be searched for a search term.



Write feedback

Have you discovered an error or do you have a suggestion for improving the application? No problem, you can send a feedback message to the responsible office in just a few quick and simple steps.

The sicon is prominently positioned in the application. Clicking this icon opens a feedback message screen, to which you can add a detailed description if necessary.

Depending on your basic settings, you can select an XSF, email or fax form.

Your administrator defines the setting as to which form is displayed.

Printed in Federal Republic of Germany / Imprimé en République fédérale d'Allemagne

Order No.: HLI 000 000 13 24

Daimler AG GSP/OR 530546 Stuttgart